



| Bearing No. | D | d1 | B |
|-------------|-------|-------|--------|
| | mm | mm | mm |
| KR16-PP | 16 mm | 6 mm | 28 mm |
| KR16-SK-PP | 16 mm | 6 mm | 28 mm |
| KR19-PP | 19 mm | 8 mm | 32 mm |
| KR19-SK-PP | 19 mm | 8 mm | 32 mm |
| KR22-PP | 22 mm | 10 mm | 36 mm |
| KR26-PP | 26 mm | 10 mm | 36 mm |
| KR30-PP | 30 mm | 12 mm | 40 mm |
| KR32-PP | 32 mm | 12 mm | 40 mm |
| KR35-PP | 35 mm | 16 mm | 52 mm |
| KR40-PP | 40 mm | 18 mm | 58 mm |
| KR47-PP | 47 mm | 20 mm | 66 mm |
| KR52-PP | 52 mm | 20 mm | 66 mm |
| KR62-PP | 62 mm | 24 mm | 80 mm |
| KR72-PP | 72 mm | 24 mm | 80 mm |
| KR80-PP | 80 mm | 30 mm | 100 mm |
| KR90-PP | 90 mm | 30 mm | 100 mm |